

DELIVERY DYNAMICS AND DESTINATION OF GENE VECTOR INSTILLATIONS IN LIVE MOUSE AIRWAYS



Martin Donnelley^{1,3,4}, Karen Siu^{5,6}, Aidan Jamison⁷, David Parsons^{1,2,3,4}

1. Respiratory and Sleep Medicine, Women's and Children's Hospital, Adelaide, South Australia
2. Women's and Children's Health Research Institute, Adelaide, South Australia
3. School of Paediatrics and Reproductive Health, University of Adelaide, South Australia, 4. Centre for Stem Cell Research,
5. School of Physics, 6. Monash Centre for Synchrotron Science, Monash University, Melbourne, Victoria
7. Division of Biological Engineering, Monash University, Melbourne




BACKGROUND: Most groups use the mouse nose as an *in vivo* model site for developing gene treatments for CF airway disease. Reliable dosing of an airway pre-treatment followed by a lentiviral vector is essential for the success of our gene transfer protocols. Despite using standardised delivery techniques we see variability in reporter-gene histological assessments and electrophysiological measurements. The aim of this experiment was to use synchrotron X-ray imaging at SPring-8 to accurately determine the fate of fluids delivered into live mouse nasal airways and the trachea.

METHODS: Nembutal anaesthetised C57Bl/6 mice (n = 6 nasal & n = 4 trachea) were imaged on the BL20B2 beamline at the SPring-8 synchrotron (Japan). For the nasal study images were captured at 1Hz. After 1 minute of baseline a 4 μ l sample of iodine-based contrast fluid (airway pre-treatment surrogate) was delivered over 10 sec. After 10 min of data collection an additional 20 μ l bolus (gene-vector surrogate) was delivered over 30 sec. Imaging continued for a further 10 min. Fluid motion was revealed using a background subtraction method. For the tracheal study mice were intubated and ventilated at 80 br/min with 1 image captured per breath. After 1 min of baseline a 15 μ l bolus (airway pre-treatment or gene-vector surrogate) was delivered over 30 sec. Following 20 min of data collection an additional 15 μ l bolus was delivered over 3.6 sec. Image capture continued for a further 10 min. Frame differencing was used to reveal fluid motion.


NASAL AIRWAY RESULTS:

- The 4 μ l dose (F1) was retained on the treated side, supporting the strength of gene expression seen in nasal ciliated epithelium and validating the use of a 4 μ l dose to retain an untreated nasal airway as a within-animal control.
- Confirms why gene expression is limited to the treated side when it extends into the tubular nasopharynx.
- Although the dose also distributes into the lateral transitional/olfactory region, expression from the gene vector was restricted to respiratory epithelium in our gene transfer studies.
- The 20 μ l dose (F2) overwhelms the 'holding capacity' of the dosed nostril, with some fluid continuing into the trachea and likely into deeper lung airways.
- Supports our finding of long term lung expression using a LV-Luc vector delivered to nose and suggests smaller vector doses may produce the same levels of nasal expression.
- Supports the proposed LPC mechanism of action since we only observe gene expression in areas reached by the 4 μ l dose, despite demonstrating the wide reach of the 20 μ l surrogate.



TRACHEA RESULTS:

- Substantial dose losses may occur upon delivery via immediate retrograde fluid motion (F3).
- Speed of bolus delivery (30 sec in F3 versus 3.6 sec in F4) into the lung may influence the relative targeting of conducting airways and deep lung.
- The fast fluid bolus delivery created larger localized increases in the contrast fluid volume that were more easily visualized (F4) using this technique.
- A bolus of fluid, marked with a red X, can still clearly be seen moving down the left main bronchus (F5) of one mouse that received 15 μ l of fluid over 30 seconds.



CONCLUSION: Synchrotron imaging can help explain the mechanisms underlying published outcomes from our gene-transduction protocols in mouse nasal airways. Our findings suggest the need for, and permit, much greater attention to dosing specifics – animal orientation, volume, speed – and enable improvements in dosing technique design.

ACKNOWLEDGEMENTS: Funding from NHMRC, Australian Synchrotron ISAP Program, JASRI and www.Cure4CF.org. We also thank Andreas Fouras, Naoto Yagi and Kentaro Uesugi.